

Step 1: Load the dishwasher with dirty glassware.



- A. Excess solid in glassware should be rinsed before putting in the dishwasher.
- B. The small compartment to the left can be used for smaller vials, septa, stoppers, etc..
- C. Residues like that of lithium salts are not washed as thoroughly via the dishwasher. I would recommend cleaning with HCl.

Step 2: Add soap to the dishwasher.



Only use the soap included below. One scoop is sufficient for a load of glassware. Close the soap holder before closing the door to the washer.



Step 3: Close the door and start the run.



The lever on the bottom should be pushed all the way to the right, the screen will light up and read 'User 1.'

Press the green "Run" button. And the load will begin running. It will take approximately two hours to run. The screen should change and read Drain/Fill.



When complete the screen will dim and glassware can be unloaded and put away/rinsed with acetone.